


Satellite **SIDEKICK** Wi-Fi Router



FIRMWARE UPGRADE



WWW.OCENS.COM

Please follow the below instructions to upgrade the firmware on your device. **(NOTE: You will need to use the Google Chrome web browser to perform this action)**

- 1) Download the upgrade file via OCENS website: www.ocens.com/sidekick#Support and save this to your desktop
- 2) Connect to your Sidekick via Wi-Fi or ethernet
- 3) Login to the Sidekick via 192.168.8.1
 - * The default password is: ocensadmin
- 4) Click on the firmware icon in the menu on the left
- 5) Click on “Upload Firmware”
- 6) Choose the file that you downloaded for the upgrade: “skxxxwebflash.bin”
- 7) Once file is uploaded verify that the “Keep settings” selection is NOT checked.
- 8) Click “Upgrade”
- 9) The upgrade is complete after the unit reboots.